


STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

BRNO APPROACH / RADAR	127.350
KUNOVICE TOWER	120.555
EMERGENCY FREQ	121.500



KUNOVICE RWY 20C

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000

Arrival via HLV2N may cross through airspace class E.
Check lower limits of TMA BRNO

