


**RNAV STANDARD DEPARTURE CHART -
INSTRUMENT (SID) - ICAO**


**PRAHA/RUZYŇĚ
RNAV SID RWY 24**



RNAV-1 required

After departure contact Praha Radar ... 120,530

PRAHA RADAR	120.530
RUZYŇĚ RADAR	127.580
SUPPLEMENTARY FREQ APP	118.310
RUZYŇĚ DELIVERY	119.010
SUPPLEMENTARY FREQ TWR	120.060
RUZYŇĚ TOWER	118.110
SUPPLEMENTARY FREQ GND	134.560
RUZYŇĚ GROUND	121.910
RUZYŇĚ ATIS	122.160
EMERGENCY FREQ	121.500



TRANSITION ALTITUDE
5000

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

DEPARTURE SPEED LIMIT BELOW FL 100	
JETS	MAX IAS 250 KT
PROPS	MAX IAS 180 KT

see AD 2-LKPR 2.22.3.3.6