


**RNAV STANDARD DEPARTURE CHART -
INSTRUMENT (SID) - ICAO**

**PRAHA/RUZYŇĚ
RNAV SID RWY 30**




RNAV-1 required

After departure contact Praha Radar ...120,530

TURN SPEED AT PR813
LIMITED TO MAX IAS 230 KT

PRAHA RADAR	120.530
RUZYŇĚ RADAR	127.580
SUPPLEMENTARY FREQ APP	118.310
RUZYŇĚ DELIVERY	119.010
SUPPLEMENTARY FREQ TWR	136.080
RUZYŇĚ TOWER	120.060
SUPPLEMENTARY FREQ GND	118.110
RUZYŇĚ GROUND	134.560
RUZYŇĚ ATIS	121.910
EMERGENCY FREQ	122.160
	121.500



TRANSITION ALTITUDE
5000

DEPARTURE SPEED LIMIT
BELOW FL 100

JETS	MAX IAS 250 KT
PROPS	MAX IAS 180 KT

see AD 2-LKPR 2.22.3.3.6

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM