


**RNAV STANDARD ARRIVAL  
CHART INSTRUMENT  
(STAR) - ICAO**

KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
SUPPLEMENTARY FREQ TWR	121.230
KARLOVY VARY ATIS	122.905
EMERGENCY FREQ	118.955
	121.500



**KARLOVY VARY  
RWY 11**

