


RNAV STANDARD DEPARTURE CHART INSTRUMENT

OSTRAVA/MOŠNOV

(SID) - ICAO


RNAV SID RWY 22



SID segments outside TMA Ostrava cross through airspace "Class E" below FL 95

Pilots who require provision of ATC service in Poland shall climb so to pass BAVOK / REGLI / NETIR at FL100 or above due to airspace "Class G" up to FL 95. If unable, advise ATC and expect vectors

OSTRAVA APPROACH / RADAR	119.375
MOSNOV DELIVERY	118.700
MOSNOV TOWER	120.805
MOSNOV ATIS	118.055
EMERGENCY FREQ	121.500



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000