



**RNAV STANDARD DEPARTURE CHART - INSTRUMENT
(SID) - ICAO**

**ČESKÉ BUDĚJOVICE
RNAV SID RWY 09**



PRAHA RADAR	118.650
BUDĚJOVICE INFORMATION	135.930
PRAHA FIC	126.100
EMERGENCY FREQ	121.500



TRANSITION ALTITUDE
5000

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM