



**RNAV STANDARD DEPARTURE CHART - INSTRUMENT
(SID) - ICAO**

**ČESKÉ BUDĚJOVICE
RNAV SID RWY 09**



PRAHA RADAR	118.650
BUDĚJOVICE INFORMATION	135.930
PRAHA FIC	126.100
EMERGENCY FREQ	121.500



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000

