


**RNAV STANDARD
DEPARTURE CHART-
INSTRUMENT (SID) - ICAO**

KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
SUPPLEMENTARY FREQ TWR	122.905
KARLOVY VARY ATIS	118.955
EMERGENCY FREQ	121.500



**KARLOVY VARY
RWY 29**

