


**RNAV STANDARD
DEPARTURE CHART-
INSTRUMENT (SID) - ICAO**

VODOCHODY RADAR	127.480
VODOCHODY TOWER	133.080
VODOCHODY RADIM	123.030
EMERGENCY FREQ	121.500



**PRAHA/VODOCHODY
RWY 10**

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000

RNAV-1 required

